



CONNOR SCONCE

INSTALLATION INSTRUCTIONS

- 1 Wear Gloves! This will protect the finish on your light, so that it will patina evenly over time.
- 2 Loosen the set screw in the slip rings on each arm using a hex key (included).
- 3 Slide the slip ring and the backplate toward the fixture and away from the crossbars, carefully not to scratch the finish.
- 4 Attach the top crossbar to the junction box.
- 5 Use a level to make sure the light is plumb and screw the crossbar attached to the lower arm into the wall.
- 6 With a licensed electrician, wire the light to the junction box.
- 7 Slide the backplates toward the wall, covering the junction box. Again, carefully not to scratch the finish.
- 8 Slide the slip ring toward the backplate and secure it into place using the hex key.

*THIS FIXTURE IS WIRED THROUGH THE TOP BACKPLATE UNLESS NOTED OTHERWISE.

KATY SKELTON™

+1 347 930 9363 | info@katyskelton.com | katyskelton.com

PROUDLY MADE TO ORDER IN SAVANNAH, GEORGIA