

*THIS FIXTURE IS WIRED THROUGH (1) BACKPLATE.

KATY SKELTON™

DOUBLE LINEAR WITH WOOD INSTALLATION INSTRUCTIONS

- Wear Gloves! This will protect the finish on your light, so that it will patina evenly over time.
- Loosen the set screw on the slip rings on each arm using the included allen wrench.
- Slide the slip ring and the backplate toward the fixture and away from the crossbars.
- Attach the top crossbar to the junction box.
- Use a level to make sure the light is plumb and screw the crossbar attached to the lower arm into the wall.
- Attach the wires from the light to the wires in the junction box (a certified electrician should be used for installation of these lights).
- 7 Slide the backplates toward the wall, covering the junction box.
- Slide the slip ring toward the backplate and secure it into place using the included allen wrench.